GTM-20

TEST METHOD FOR THE GRAIN-SIZE ANALYSIS OF GRANULAR SOIL MATERIALS



GEOTECHNICAL TEST METHOD GTM-20

Revision #6

APRIL 2022



Department of Transportation

Office of Technical Services

Geotechnical Engineering Bureau

TABLE OF CONTENTS

1.1.	SCO	PE3	
2.	SUN	IMARY OF METHOD	
3.	EQU	IPMENT	
4.		MPLE SIZE AND PREPARATION	
	4.1	Sample Size for Granular Construction Items Sample Size for All Other Materials	
	4.2	Sample Size for All Other Materials	
	4.3	Prepare Sieve Analysis Data Sheet	
	4.4	Γ PROCEDURE	
5.	5.1	Initial Separation of the Plus and Minus 1/4 in. (6.3 mm) Particles6	
	5.1	Weigh the Plus 1/4 in. (6.3 mm) Portion of the Sample	
	5.3	Sieve the Dive 1/4 in (6.3 mm) Material	
	5.4	Waint the Minus 1/4 in (6.3 mm) Portion of the Sample	
	5.5	Determine the Moieture Content of the Minus 1/4 in. (0.3 mm) Material	
	5.6	Wach the Minus 1/4 in (6.3 mm) Sample	
	57	Siave the Minus 1/4 in (6.3 mm) Sample	
6.	COM	DIFTATIONS	
	6.1	P 11 37 1	
	6.2	Correct the Weight of Minus 1/4 in (6.3 mm) Material for Moisture Content10	
	0.2	CO 1 Determine the Moieture Content	
		62.2 Commute the Day Weight of the Minus 1/4 in. (6.3 mm) Material	,
	6.3		,
	6.4	Community the Destine Size Distribution of the Plus 1/4 In. (0.5 IIIII) Material	~
	0.4	6.4.1 Compute the Percent Retained	U
		Camerate the Percent of Total Sample Passing	1
	6.5	2 the Porticle Size Distribution of Minus 1/4 in. (6.3 mm) Material	1
	0.5	and the Descent Detained	
		652 Compute the Percent Passing Based on Minus 1/4 in. (0.3 mm) Material I	11
		and the Descent Passing Hased on Total Weight	11
		G	11
	6.6	TO LAT ANCEC	14
7.		Check the Computed Percent Retained.	12
	7.1	7.1.1 For the Plus 1/4 in. (6.3 mm) Material	12
		7.1.1 For the Plus 1/4 in. (6.3 mm) Material	12
		7.1.2 For the Minus 1/4 in. (6.3 mm) Material	12
	7.2	Check the Computed Percent Passing.	12
		T 1/4 in (6.2 mm) Material	
		7.2.1 For the Plus 1/4 in. (6.3 mm) Material	14
-	TD TA		1
PPEN	NDIX	Sieve Analysis Data	A-
	A.	Requirements of Sieves	B-
	R	Requirements of Sieves	

3. EQUIPMENT

The following equipment is required for this test:

- Platform Scale

 With a capacity of at least 36 lbs. (16 kg). The scale shall be accurate, and be readable to 0.01 lb (5 g).
- Balance Triple beam or other with a capacity of at least 5½ lbs. (2500 g). It shall be accurate, and be readable to 0.1 g.
- Sieves A series of sieves which conform to the requirements of AASHTO M-92-91, page 87 Table No. 1 (excluding Column 7). See Appendix B.
- Containers Metal pans of sufficient size to contain at least 1.1 lb. (500 g) of material for moisture content determination.
- Large Pans Metal pans of sufficient dimension to contain the total sample for mixing and conditioning.
- An infrared dryer, oven, hot plate or stove capable of drying samples without causing alteration of the material's particle size or shape, and without causing the loss of material. Ovens must have a temperature control and be capable of maintaining a temperature of 230°± 9° F (110°± 5° C). If a stove or hot plate is used, a bed of sand is required between the sample containers and heat source
- Miscellaneous

 A flat bottom scoop, a wood mallet, an assortment of brushes, a large weighing pan for the platform scale and leveling boards for the platform scale and balance.

5. TEST PROCEDURE

During the entire test, care should be exercised to prevent the loss of sample material. This entails proper labeling and organization of the samples as well as careful transference of material during the test. When the procedure requires several separations (or sievings), be sure to keep each of the sieved portions together for further tests and weighings. Only after all of the tests, checks, and balances have been successfully completed, may any portion of the sample be discarded.

When testing small samples, perform all weighings using the balance rather than the platform scale, as prescribed in the procedure. Record the values to the nearest 0.1 g. Form SM 15b uses US Customary Units (lbs.) for recording the larger weights (weight Plus ¼ in. (6.3 mm) material, etc.) and International System of Units (g) for recording the smaller weights (moisture content, weight Minus ¼ in. (6.3 mm) material, etc.).

5.1 Initial Separation of the Plus and Minus ¼ in. (6.3 mm) Particles.

Screen the moist or dry sample on a ¼ in. (6.3 mm) sieve in order to divide it into plus ¼ in. (6.3 mm) and minus ¼ in. (6.3 mm) portions. If an excessive amount of silt or clay adheres to the plus ¼ in. (6.3 mm) material, it should be screened again after additional drying. If the sample does not have any plus ¼ in. (6.3 mm) particles, proceed in accordance with Section 5.4.

- Note 1. During this initial sieving, care should be exercised to prevent "overloading" the ¼ in. (6.3 mm) sieve. This condition exists when an excessive amount of soil is placed on the sieve, leaving an insufficient amount of sieve openings for the material to pass through. To avoid "overloading", the sample must be divided into smaller portions and sieved separately.
- Note 2. In some soils a significant amount of the particles will adhere together and form silt and/or clay balls, which may be mistaken for plus ¼ in. (6.3 mm) particles. Care must be taken to insure that such balls pass through the ¼ in. (6.3 mm) screen. It may be necessary to run a wood mallet over the material on the screen for this purpose, but be careful not to pulverize the actual particles or damage the sieve.

5.2 Weigh the Plus 1/4 in. (6.3 mm) Portion of the Sample.

Once the plus ¼ in. (6.3 mm) portion has fully dried (to the point where there is no visible sign of moisture), weigh the sample to the nearest 0.01 lb. and record this value on Line A of the data sheet.

Note 1. Prior to weighing the plus ¼ in. (6.3 mm) portion, check for particles larger than 4 in. (100 mm). Remove such material and weigh it to the nearest 0.01 lb. and make a note of it on the data sheet. These particles should not be included in the test.

5.3 Sieve the Plus ¼ in. (6.3 mm) Material.

The series of sieves used shall comply with the particle size requirements of the material being tested or as requested by the Engineer or Laboratory Supervisor. The sieves shall be arranged

- Note 3. If an oven is used, the sample should be maintained at a temperature of 230°± 9° F (110°± 5° C) for a minimum of 12 hours or until it maintains a constant weight.
- Note 4. When a sample contains less than 1 lb. (500 g) of minus 1/4 in. (6.3 mm) particles, moisture content and gradations (Sections 5.5, 5.6 & 5.7) may be performed on the smaller amount only if the sample is considered to be representative by the requestor.

5.6 Wash the Minus ¼ in. (6.3 mm) Sample.

Obtain a 300 ± 5 g portion of the moisture content sample (from Section 5.5) and record this weight to the nearest 0.1 g on Line N of the data sheet. Wash this sample on a No. 200 (0.075 mm) sieve to remove all fines from the sample. It is suggested to wash the sieve sample over a white basin to make it easier to see when the wash water is clean. After the sample is thoroughly washed, carefully transfer the sample from the sieve to a container for drying. Dry the sample in accordance with the provisions of Section 5.5. Weigh the dried sample to the nearest 0.1 g and record this value on Line O of the data sheet.

- Note 1. Examine the No. 200 (0.075 mm) sieve prior to each washing to determine its condition. Replace the sieve if any holes or cracks are noticed in the solder or mesh, or if the sieve's mesh is stretched excessively. A new No. 200 (0.075 mm) sieve must be washed with soap and water prior to initial use.
- Note 2. Place sample directly on wash sieve and, while sample is under stream of water, agitate back and forth using motion similar to hand sieving dry material.
- Note 3. The No. 200 (0.075 mm) sieves are delicate. Fingertips may be used to agitate the sample to breakdown soil aggregations during washing, but do not apply pressure to the mesh itself.
- Note 4. Do not allow water to overflow or splash out of the sieve. This may cause a loss of material and lead to inaccurate results. Tapping the side of the sieve will help break the surface tension as well as eliminate clogging.

5.7 Sieve the Minus 1/4 in. (6.3 mm) Sample.

Sieve the dry washed sample remaining from Section 5.6. The series of sieves used shall comply with the particle size requirements of the material being tested or as requested by the Engineer or Laboratory Supervisor. The sieves shall be arranged such that the largest mesh sieve is on top, with the mesh sizes progressively decreasing. The last sieve should be the No. 200 (0.075 mm) followed by a "pan". Weigh the material retained on each sieve and the "pan", and record the weights to the nearest 0.1 g in Column 5 of the data sheet. Sum the values in Column 5 and record this value at the bottom of that Column.

veights

6. COMPUTATIONS

6.1 Rounding Numbers.

For all computed results, round the values in the following manner: Compute the values to one place beyond the required significant figures. If the extended value is less than 5, leave the last required digit unaltered. If it is greater than 5, round the last required digit up one unit. If the extended value equals 5, round the last required digit to the nearest even number.

- 6.2 Correct the Weight of Minus 1/4 in. (6.3 mm) Material for Moisture Content.
 - 6.2.1 Determine the moisture content.

Compute the weight of water by subtracting Line I from Line H and record this value on Line K. Compute the weight of dry material by subtracting Line J from Line I and record this value on Line L. Compute moisture content by dividing weight of water (Line K) by the weight of the dry material (Line L) and multiply this value by 100 and record to the nearest 0.1% on Line M.

% Moisture Content,
$$M = \frac{H-I}{I-J} \times 100$$

6.2.2 Compute the dry weight of the minus ¼ in. (6.3 mm) material.

Divide the total weight of minus ¼ in. (6.3 mm) material (Line D) by the quantity 1 plus the moisture content (Line M) divided by 100 and record this value on Line E.

Weight of dry minus 1/4 in (6.3 mm), E = D + (1 + (M + 100))

6.3 Compute the Total Dry Weight of the Sample.

Compute the total dry weight by adding the dry weight of the plus ¼ in. (6.3 mm) material (Line C) to the dry weight of the minus ¼ in. (6.3 mm) material (Line E) and record this value on Line F.

Total Dry Weight,
$$F = C + E$$

- 6.4 Compute the Particle Size Distribution of Plus 1/4 in. (6.3 mm) Material.
 - 6.4.1 Compute the percent retained.

Divide the weight retained on each sieve (in Column 1) by the total dry weight of the sample (Line F). Multiply each value by 100 and record the results to the nearest 0.1% in Column 2 opposite the respective sieve. Sum the values in Column 2 and record this value at the bottom of Column 2.

7. CHECKS AND BALANCES

7.1 Check the Computed Percent Retained.

7.1.1 For the plus ¼ in. (6.3 mm) material. The total weight retained (Total of Column 1) divided by the total dry weight of the sample (Line F) and multiplied by 100, should be no more than ±0.2% from the sum of the percents retained (Total of Column 2).

$$\sum of \ Column \ 2 = \frac{\sum of \ Column \ 1}{Line \ F} \times 100 + _0.2\%$$

7.1.2 For the minus ¼ in. (6.3 mm) material.

The total weight retained (Total of Column 5) minus the "Pan" material, divided by the weight of dry minus ¼ in. (6.3 mm) material before wash (Line N) and multiplied by

100, should be no more than $\pm 0.2\%$ from the sum of the percents retained (Total of Column 6).

$$\sum of \ Column \ 6 = \frac{(\sum of \ Column \ 5 \ _Pan)}{Line \ N} \ x \ 100 + _0.2\%$$

7.2 Check the Computed Percent Passing.

7.2.1 For the plus 1/4 in. (6.3 mm) material.

The sum of the percent retained (Total of Column 2) plus the percent of total sample passing the ¼ in. (6.3 mm) sieve (last value of Column 3) must equal 100%.

$$\sum$$
 of Column 2 + last value of Column 3 = 100%

7.2.2 For the minus 1/4 in. (6.3 mm) material.

The sum of the percent retained (Total of Column 6) plus the percent passing the No. 200 (0.075 mm) sieve, based on minus ¼ in. (6.3 mm), (last value of Column 7), must equal 100%.

 \sum of Column 6 + last value of Column 7 = 100%

APPENDIX A - Sieve Analysis Data

Projec										
Project			G	EOTECHNICA	L ENGINE	EDING 6	UPPAIL			
27.00	1	Marian Company		SIEVE	ANALYS	IS DATA	UREAU			
PIN							Semmost			
Region		Count	Contract No.			PROJECT	STAMP		-	
Anteri	al Source	Coon	y.			-				
ocati	on	Offse				1				
em N	0			Depth		1				
ampl	No.									- C
LINE		SAME	PLE WEIGHTS							
A	WL OF D	FIRE U.S COM After to	DECEMBER 1			LINE	Parallel and the control	MOISTURE CON	TENT (Gran	ms)
0	THE U	"Bit" Material from Phos	D. S. communication	lbs lbs		Н	Container Number		des	
C	Wt. of D	by Plus 6.3 mm Stanch	115 60	Be		100	Wt. of Symple & Container Before Drying g			
D	WE OF N	foist Minus 6.3 mm Mars	nelat	THE RESERVE AND ADDRESS OF THE PERSON NAMED IN		1	Vn. of Container After Drying g			
E TWIL OI Dry Minus 6,3 min Dei		ry Minus 6.3 min Derse	Ne(MC+1000 the			К	Wr. of Container g			
F	Wh. of Te	otal Dry Sample (C = E)	The same of the sa	Ibs		L	Wt. of Dry Sample			
-	-		-			М	Moisture Content		10,15	
5	REVE	1	-	2	12 2	B.H	3	4		100
		WEIGH	cr	16	Fire S	%0	F TOTAL	WHOLE NO.	201	SPECIFICATION
mm	in.	RETAINED	(bs)	RETAIN	ED		E PASSING	% PASSING		REQUIREMENT
00	4		- anna	11	ro n					
75	3	-73.61		N INC.		0,6	18.24			The state of the s
50	2		Tream, 970		COUNTY!		2253			
7.5	1 1/2		90m 25	A STATE OF THE PARTY NAMED IN	COURSE OF	02	23,85			
5.0	1	AL REDE	E1412.7		(met le	No.	5154			The same and
9.0	3/4	100 12 2	A STATE OF	N. L.	Same C	DE.	2323		The same of	100
_	1/2	THE RESERVE OF THE PERSON NAMED IN								
-3	1/4	The state of the s	The state of		ma L		cors			
_	3/8	Total Control of the	mins.	LO .	INCO L		0000			
5	3/8	2000			mo L		2013			
	3/8 1/4 TAL	S. Leave Gallery Man	h (oms)		d and		60,1			
TO VL of	3/8 1/4 TAL Dry Minus	s 6.3 mm Before Wash (14 15 15 15 15 15 15 15 15 15 15 15 15 15	.4	P. Plás	mostly hiddicator		men =	n in Cla
TO TL of	3/8 1/4 TAL Dry Minus		(gms)	6	0	104	6	9	10	d marks
TO VIL of I	3/8 1/4 TAL Dry Minus	6.3 mm After Wash ((gms)		% PASSIN	7 NG BASED	8 % OF TOTA	r MHOIE	NO.	SPECIFICATION
TO TL of I	3/8 1/4 TAL Dry Minus Ory Minus VE MATION	a 6.3 mm After Wash ((gms)		% PASSIN	104	6	r MHOLE	NO.	d marks
TO L of I	3/8 1/4 TAL Dry Minus Ory Minus	5 WEIGHT	(gms)	4	% PASSIN	7 NG BASED	8 % OF TOTA	r MHOIE	NO.	SPECIFICATION
TO TL of I	3/8 1/4 TAL Dry Minus Ory Minus V6 IATION No. 4	5 WEIGHT	(gms)	4	% PASSIN	7 NG BASED	8 % OF TOTA	r MHOIE	NO.	SPECIFICATION
TO TO OF SIE SIGN	3/8 1/4 TAL Dry Minus V6 UATION No. 4	5 WEIGHT	(gms)	4	% PASSIN	7 NG BASED	8 % OF TOTA	r MHOIE	NO.	SPECIFICATION
TO TL of I	3/8 1/4 TAL Dry Minus Ory Minus VE IATION No. 4 10 20	5 WEIGHT	(gms)	4	% PASSIN	7 NG BASED	8 % OF TOTA	r MHOIE	NO.	SPECIFICATION
TO TE OF SIE	3/8 1/4 TAL Dry Minus Ory Minus VE VATION No. 4 10 20 46	5 WEIGHT	(gms)	4	% PASSIN	7 NG BASED	8 % OF TOTA	r MHOIE	NO.	SPECIFICATION
TO VIL of I	3/8 1/4 TAL Dry Minus Ory Minus Ove HATIGN No. 4 10 20 40 60	5 WEIGHT	(gms)	4	% PASSIN	7 NG BASED	8 % OF TOTA	r MHOIE	NO.	SPECIFICATION
TO TL of 1	3/8 1/4 TAL Dry Minus Ove Minus VE IATIGN No. 4 10 29 46 60 100	5 WEIGHT	(gms)	4	% PASSIN	7 NG BASED	8 % OF TOTA	r MHOIE	NO.	SPECIFICATION
TO PL of I	3/8 1/4 TAL Dry Minus Ory Minus Ove HATIGN No. 4 10 20 40 60	5 WEIGHT	(gms)	4	% PASSIN	7 NG BASED	8 % OF TOTA	r MHOIE	NO.	SPECIFICATION
TO VIL of I	3/8 1/4 TAL Dry Minus VE LATION No. 4 10 20 40 60 100 200 8	5 WEIGHT	(gms)	4	% PASSIN	7 NG BASED	8 % OF TOTA	r MHOIE	NO.	SPECIFICATION
TO VIL of 1 SIE ESIGN 5 0 0 5 5 6 6 7 7 7 7 7 7 7 7 7 7 7	3/8 1/4 TAL Dry Minus VE LATION No. 4 10 20 40 60 100 200 8	5 WEIGHT	(gms)	4	% PASSIN	7 NG BASED	8 S OF TOTAL SAMPLE PASS	L WHOLE	NO. SING	SPECIFICATION REQUIREMENT
TO VIL of I	3/8 1/4 TAL Dry Minus VE LATION No. 4 10 20 40 60 100 200 8	5 WEIGHT	(gms)	AINED	% PASSIP ON MINU	7 NG BASED	8 % OF TOTA	L WHOLE	NO.	SPECIFICATION